# INSTALLATION INSTRUCTIONS

For Model # P442-084, P442-467

#### **READ AND SAVE THESE INSTRUCTIONS**

### ${f W}$ arning! Shut power off at fuse or circuit breaker.

### AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

#### **MOUNTING THE BACKPLATE (Fig. 1)**

- 1. Shut off power at the circuit breaker and remove old fixture, including the mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
- 3. Attach the Mounting Plate (A) to the Outlet box (C) with two screws (B). The side of the mounting plate marked "GND" must face out.

#### **CONNECTING THE WIRES (Fig. 2)**


4. At this point, connect the electrical wire as shown in figure 2, making sure that all wire connectors are secured. If your outlet has a ground wire (green or bare copper), connect the fixtures Ground Wire to it. Otherwise, connect the fixture Ground Wire directly to the crossbar using the Green Screw provided.


## FINISH MOUNTING FIXTURE (Fig. 1)

- Place the Fixture Body (D) over the Mounting Plate (A). Adjust the Fixture Body (D) and let the Studs (E) slide into the slot of Fixture Body (D). Tighten the Studs (E).
- Install Xenon bulb (F) into socket in accordance with the fixture's specifications. (DO NOT EXCEED THE MAXIMUM WATTAGE RATING!)
- 7. Screw Glass Shade (G) onto the Socket.

Your installation is now complete. Return power to the junction box and test the fixture.

Note: Illustration (Fig.1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.





IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.

